

FIG.







2/15



3/15





# *FIG.* 5

DEVICE ID	DEVICE TYPE	
IP CONFIG (S	STATIC/DHCP)	
TELCO LOGINS		
TUNNEL ID		
•   •   •		
WEB SERV	ER PAGES	
GUI INFO		
DNS INFO		
DHCP INFO		
PPP	INFO	




FIG. 7

LOG IN

USER ID:  PASSWORD:
LOG IN

FIG. 12

{SYSTEM MESSAGE} AS OF {PC TIME}	STATUS
{ERROR MESSAGE}	DISCONNECT
	VIEW SYSLOG
	CLOSE
AT&T WORLDNET  @HOME  UUU ••• UU  VVV ••• VV  WWW ••• WW  XXX ••• XX  YYY ••• YY  ZZZ ••• ZZ   CONNECT EDIT COPY	·

FIG. 8

{SYSTEM MESSAGE} AS OF {PC TIME} {ERROR MESSAGE}	STATUS  DISCONNECT  VIEW SYSLOG  CLOSE	
SELECT A CONNECTION FROM THE LIST OR CREATE A  AT&T WORLDNET  @HOME  UUU • • • UU  VVV • • • VV  WWW • • • WW  XXX • • • XX  YYY • • • YY  ZZZ • • • ZZ     V		
CONNECT EDIT COPY DELETE		

*FIG.* 9

STATUS  {SYSTEM MESSAGE} AS OF {PC TIME}  {ERROR MESSAGE}  VIEW SYSLOG  CLOSE		
SELECT A CONNECTION FROM THE LIST OR CREATE A NEW CONNECTION.  AT&T WORLDNET  @HOME  UUU • • • UU  VVV • • • VV  WWW • • • WW  XXX • • • XX  YYY • • • YY  ZZZ • • • ZZ   DIAL—UP CONNECTION — {NAME OF CONNECTION}  USER ID: {USER ID} PASSWORD: *************  PHONE NUMBER  TO DIAL:  #70 TO DISABLE CALL WAITING.		

FIG. 10

{SYSTEM {ERROR	MESSAGE} AS OF {PC TIME} MESSAGE}	STATUS  DISCONNECT  VIEW SYSLOG  CLOSE
SELECT A CON  AT&T WORLDNET  @HOME  UUU • • • UU  VVV • • • VV  WWW • • • WW  XXX • • • XX  YYY • • • YY  ZZZ • • • ZZ	DIAL-UP CONNECTION -  USER ID: {USER ID} PAS  CUSTOMIZED MODEM DIAL  ATDT*70, 18005551234,	{NAME OF CONNECTION} SWORD: ********* STRING:

# FIG. 11

{SYSTEM MESSAGE} AS OF {PC TIME} {ERROR MESSAGE}	STATUS  DISCONNECT  VIEW SYSLOG  CLOSE
SELECT A CONNECTION FROM THE LIST OR CREATE A  AT&T WORLDNET — NETWORK CONNECTION  WHOME  UUU • • • UU  VVV • • • VV  WWW • • • WW  XXX • • • XX  YYY • • • YY  ZZZ • • • ZZ  CONNECT EDIT COPY	N - {NAME} _ADDRESS} ASK_ADDRESS}

FIG. 13

### CONNECTING •••

CONNEC	T TO {NAME} • • •	STATUS DISCONNECT
		VIEW SYSLOG
		CLOSE
VCS OFFICE(SM) VCS AGENT(SM) PAT	SERVICE NAME} LOGIN  SERVICE URL: http://aaaa.resect.  SUBSCRIBER ID: 123.45.67.89  PASSWORD: 255.0255.0  SAVE PASSWORD  LOGIN  TRY AGAIN MAIN ME	rch.att.com/bbb/ccc

FIG. 14

## **NEW CONNECTION**

Step 1: Name		
WHAT IS THE NAME OF THIS CONNECTION?		
Step 2: Connection Type		
O DIAL-UP CONNECTION  A DIAL-UP CONNECTION USES A MODEM AND OBTAINS CONNECTION BY DIALING INTO A NUMBER.	NETWORK CONNECTION     A NETWORK CONNECTION USUALLY     CONNECTS THROUGH LOCAL AREA     NETWORK (LAN), CABLE MODEM,     OR DSL.	
Step 3: Specific Information		
FOR DIAL UP CONNECTION • • •	FOR NETWORK CONNECTION • • •	
USER ID:  PASSWORD:  USE STANDARD DIAL-UP CONFIGURATION  PHONE NUMBER TO DIAL:  - OPTION: DIAL  TO ACCESS ON OUTSIDE LINE.  - OPTION: DIAL  TO DISABLE CALL WAITING.  - OR -  USE CUSTOMIZED MODEM DIALING STRING	O USE DHCP  HOST:  - OR -  USE FIXED IP ADDRESS  IP ADDRESS:  MASK:  GATEWAY:	
SAVE START	OVER CANCEL	

FIG. 15

### **EDIT CONNECTION**

NAME: [{NAME}	DIAL-UP CONNECTION	
USER I		
USE STANDARD DIAL-UP Co	ONFIGURATION	
PHONE NUMBER TO DIA  - OPTION: DIA  - OPTION: DIA	AL 9 TO ACCESS AN OUTSIDE LINE.	
- OR -  Ouse customized dialing string		
SAVE SAVE AS	START OVER CANCEL	

FIG. 16

### **EDIT CONNECTION**

NAME:	NETWORK CONNECTION	
{NAME}		
• USE DHCP		
CLIENT:		
- OR  Ouse customized dialing string		
IP ADDRESS: 1	23.45.678.90	
MASK: 2	255.254.253.252	
GATEWAY: 123.4.56.789		
SAVE START OVER CANCEL  SAVE AS >>>		
SAVE AS >>>		